


# i DISPLAY Retail Tablet Adjustable Shelf Clip

Product Specification & Assembly Instructions






i Display's range of fixtures are the perfect retail accessory for your i Display Retail Tablet and Android Advertising Display.

The Shelf clip gives you a complete solution to secure your display to any shelf location within the store.


The i Display Retail tablet Shelf clip is made from high-quality materials and is very simple to assemble.






# **Product Specification**


#### LXWXHmm









7" highest hole horizontal position 190 X 300 X 162



7" highest hole vertical position 122 X 300 X 196




7" lowest hole horizontal position 190 X 300 X 147




7" lowest hole vertical position 122 X 300 X 190





10.2" highest hole horizontal position 270 X 296 X 186

10.2" highest hole vertical position 180 X 296 X 270




10.2" lowest hole horizontal position 270 X 296 X 180


10.2" lowest hole vertical position 180 X 296 X 270



#### Angle rotation range.




#### Shelf Clip general dimensions.






## **Components**




Shelf clip






### **Assembly Instructions**

# Step 1 Choose the desired adjustable hole, then connect the Front panel to the base of Shelf Mount using the position screw.





Step 2
Peel off the protective paper on the 3M stickers, then stick the Shelf mount on the surface of shelf where you want the Retail Tablet placed.




For further information or support, please contact <a href="mailto:support@i-display.com">support@i-display.com</a>




#### Step 3

If you desire to affix the larger sized Retail Tablet (over 15.6"), we suggest you affix the Shelf mount with screws as described in the picture below, this will increase the stability of the unit.






Step 4
Connect the Retail Tablet with the Shelf mount by using the 4pcs of the thumb screws.





Step 5
Plug in the DC cord to the Retail Tablet. Pass the wire through the wire hole.





Step 6 You can adjust and set the angle of the Retail Tablet by adjusting the angle screw as below.

