



Logitech®

Harmony 555 Remote Control

Sleek and strong

- A comfortable and simple design with just the commands you need to be in complete control
- Simple one-touch activity control One button does it all
- Online Internet Database with access to thousands of codes for an easy set up
- World's largest A/V control database makes it work with almost all brands
- Replaces up to 15 remote controls
- Sound and picture buttons for quick access to your favorite functions
- Full product support
- 2 year guarantee

Finally, complete control with one remote. Simple computer based set-up allows for control of your home entertainment devices with the touch of one button. Choose "Watch DVD" and this will power on the TV, DVD, and stereo receiver, set the inputs, and even press play. The Harmony 555 gives you full control of up to 15 devices from an on-line database that includes 3,500+ brands and 125,000+ devices - everything from HDTV's to DVD's, from laserdiscs to VCR's, even lighting controls and more! And it's updated every day, so you're always in control.

















Logitech®

Harmony 555 Remote Control



Package specifications

| | Single Pack | Inner carton/ Case pack | Master Shipper/ Out Case pack |
|--------------------|---------------------|-------------------------|-------------------------------|
| Part #: | 966208-0914 | n/a | n/a |
| Bar Code (EAN-13): | 5 099 206 989 337 | | 5 099 206 989 3325 |
| Weight | 505 g | kg | 2.350 kg |
| Width | 7.10 cm | cm | 38.30 cm |
| Depth | 19.10 cm | cm | 21.00 cm |
| Height | 30.40 cm | cm | 20.50 cm |
| Volume | 4.1 cm ³ | m³ | 0.01649 m³ |
| 1 Single Carton | 1 Single unit | NC | NC |
| 1 Case Pack | 4 Single units | NC | NC |
| 1 Outer Case Pack | Single units | | Out Case Pack |
| 1 Pallet | 400 Single units | Case Packs | Out Case Packs |
| 1 Container 20 ft | 7480 Single units | Case Packs | Out Case Packs |
| 1 Container 40 ft | 15268 Single units | Case Packs | Out Case Packs |

Package contents

- Harmony 555 remote control
- USB cable
- Installation CD
- Installation guide
- 4 AAA batteries



www.logitech.com

