


i DISPLAY

Interactive Digital Displays

Table Bracket

Product Specification & Assembly Instructions




i DISPLAY

Interactive Digital Displays

i Display's range of fixtures are the perfect retail accessory for your i Display Retail Tablet and Android Advertising Display.

The table bracket gives you a complete solution to secure your display to any table location within the store.

The i Display Retail tablet table bracket is made from high-quality materials and is very simple to assemble.






For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Product Specification


L X W X H mm




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays






Retail Tablet S
190 X 120 X 62



Retail Tablet M
270X 175 X 67

For further information or support, please contact support@i-display.com

Table Bracket general dimensions



i DISPLAY

Interactive Digital Displays

Components






Table Bracket




Screw Driver



Screw - Short (2pc)



Screw - long (4pc)



thumb screw (4pc)

For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays


Assembly Instructions

There are 2 options to affix the Table Bracket.
(Free location and fixed location)

For free location method

Step 1

Use the screw driver to loosen the screws to separate plates.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 2

Connect the Metal Vesa plate with the Retail Tablet using 4pcs of the Thumb screws.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 3

Pass the DC wire as shown, then insert the metal bottom plate into the metal vesa plate.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 4

Using short screws reconnect the metal vesa plate and the metal bottom plate together. Then plug the DC jack into the Retail Tablet.



For further information or support, please contact support@i-display.com


i DISPLAY

Interactive Digital Displays

For fixed location method

Step 1

Use the screw driver to loosen the screws to separate plates.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 2

Use long screws to affix the metal bottom plate on the table of your choosing.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 3

Connect the metal vesa plate with the Retail Tablet using 4pcs of the thumb screws.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 4

Pass the DC wire as shown, then plug the DC jack into the Retail Tablet.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 5

Slide the Retail Tablet onto the metal bottom plate.




For further information or support, please contact support@i-display.com

i DISPLAY

Interactive Digital Displays

Step 6

Using short screws reconnect the metal vesa plate and the metal bottom plate together.



For further information or support, please contact support@i-display.com